

# LOCK'ER<sup>®</sup> DOWN

## SECURITY PRODUCTS

## INSTALLATION INSTRUCTIONS

### LD2014/LD2014EX

[2007 to 2014 Silverado, Suburban, Tahoe, and GMC Sierra, Yukon, Yukon XL  
with Split Bench]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the padding from the bottom of the inside of the safe.
4. Set the safe into the center console.
5. Using your **DRILL** or **PHILLIPS SCREWDRIVER** fastening device, insert the **LOCK'ER DOWN PROVIDED SELF TAPING SCREWS** into the set holes in the side of the safe.
6. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
7. Re-insert the padding that was removed from the safe before installation.
8. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **PHILLIPS SCREWDRIVER**

**Contents Included:** 4 Self Tapping Screws.

