

# LOCK'ER<sup>®</sup> DOWN

## SECURITY PRODUCTS

## INSTALLATION INSTRUCTIONS

### LD2019/LD2019EX

[2007-2013 Chevrolet Avalanche]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now
3. Remove the **4** screws that are holding down the center console.
4. Insert the lid assembly diagonally with the lock facing forward towards the dash, then turn the lid assembly inside the console so that the outline matches with the console compartment outline (see images on back for exact orientation).
5. With the lid **OPEN**, insert the right-side bracket first (this is the side with the USB cable), then the left side bracket (see images on back for side descriptions)
  - a. Once the sides are inserted over the bolts on each side of the lid assembly, apply the **LOCK'ER DOWN** provided nuts to each of the four bolts.
6. Using an **IMPACT DRILL** or **SCREWDRIVER**, apply the **4** self-tapping screws into each of the four slots (**2** on the bottom section of each bracket) and through the floor of the console.
7. Remove the padding from the bottom of the inside of the safe.
8. Tighten the screws and nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE OR SAFE!**
9. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH, SCREWDRIVER**
- 13mm Socket bit

**Contents Included:** **4** 13mm Nuts.

**4** Black Self Tapping Screws.

