



LD2041 Install
Video

LOCK'ER[®] DOWN

Security Products **INSTALLATION INSTRUCTIONS**

LD2041/LD2041EX

[2014-2019 Chevrolet Silverado and GMC Sierra 1500, also 2015-2020
Chevrolet and GMC 2500,3500]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now.
3. Remove the neoprene padding from the inside of the safe.
4. Place the safe into the console compartment.
5. Using a **1/8 DRILL BIT** along with a drill, pre-drill pilot holes into the console compartment where the screws will be set.
 - a. The screws will be set in the two holes on either side of the safe.
 - b. Make sure to drill through until the drill hits metal.
 - c. To make this process easier, mark the locations where the holes will be drilled, remove the safe, then drill the pilot holes into the console compartment.
6. If you removed the safe from **Step 4: c)**, reinsert the safe into the console compartment.
7. Secure the safe into the console compartment using the **4 SELF TAPING SCREWS** provided by **LOCK'ER DOWN**, these screws are to be set into the pre-drilled pilot holes from **Step 4**.
8. Tighten the screws, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
9. Re-insert the padding that was removed from the safe before installation.
10. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **PHILLIPS SCREWDRIVER**
- 1/8 Drill Bit
- Phillips Head Drill Bit (optional)

Contents Included: 4 Self Tapping Screws

