



LD2042 Install
Video

LOCK'ER[®] DOWN

SECURITY PRODUCTS

INSTALLATION INSTRUCTIONS

LD2042/LD2042EX

[2015 to 2020 Chevrolet Suburban and Tahoe, and GMC Yukon, and Yukon XL/ 2014 to 2019 Chevrolet Silverado and GMC Sierra 1500, also 2015 to 2020 Chevrolet and GMC 2500, and 3500]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the **2** plastic file holders on either side of the console compartment.
 - a. These are removed by pulling outward on the center of the tab, then forward towards the front of the console.
4. Remove the **2** 10mm bolts at the bottom of the console compartment.
5. Remove the padding from the bottom of the inside of the safe.
6. Set the safe into the center console.
 - a. To ensure that the console is set in properly, make sure that the factory cut holes at the **BOTTOM** of the safe line up with the bolt holes from **STEP 5**.
7. Using your 10mm fastening device, insert the **LOCK'ER DOWN PROVIDED 10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
8. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
9. Re-insert the padding that was removed from the safe before installation.
10. Re-insert the 2 file holders that were removed in **STEP 3**.
11. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 10mm Socket bit

Contents Included: **2** 10mm Bolts.

