

## [2010-2022 Toyota 4Runner]

- 1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
- 2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
- 3. Remove the neoprene padding from the inside of the safe for now.
- 4. Remove the **2** Bolts at the bottom of the console compartment.
- 5. Set the safe into the center console.
  - a. The slots at the bottom of the safe should line up with the slots where the bolts were removed from **Step 4**.
- 6. Secure the safe to the console compartment using the **2 10mm BOLTS** provided by **LOCK'ER DOWN**.
- 7. Tighten the bolt, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
- 8. Re-insert the padding that was removed from the safe before installation.
- 9. Enjoy your purchase!

## **Tools Needed:**

- IMPACT DRILL or SOCKET WRENCH
- 10mm Socket bit

Contents Included: 4 10mm Bolts.



LD2048 Install Video

