

# LOCK'ER<sup>®</sup> DOWN

## INSTALLATION INSTRUCTIONS

### LD2052

[2015-2022 GMC Canyon]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the neoprene padding from the inside of the safe for now.
4. Set the safe into the center console.
  - a. To ensure the safe is in the console correctly, make sure that the lock is closest to the front of the console compartment at the top.
5. Secure the safe to the console compartment using the **3 SELF TAPPING SCREWS** provided by **LOCK'ER DOWN**.
  - a. To secure the safe to the console properly, **2** of the self-tapping screws should be inserted in the back of the safe through the factory cut holes in the safe, and **1** self-tapping screw in the front of the safe through the factory cut holes in the safe.
6. Tighten the screws, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
7. Re-insert the padding that was removed from the safe before installation.
8. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **PHILLIPS HEAD SCREWDRIVER**
- Phillips Head Drill bit (for the use of a Drill)

**Contents Included:** 4 Self Tapping Screws

