

LOCK'ER[®] DOWN

Security Products

INSTALLATION INSTRUCTIONS

LD2067

[2011-2022 Jeep Grand Cherokee and Dodge Durango]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now.
3. Remove the neoprene padding from the inside of the safe for now.
4. Remove the **TOP PLATE** from the safe assembly and set the **BOTTOM ASSEMBLY** into the console compartment.
5. Set the **TOP PLATE** onto the bottom safe assembly by tilting the top plate forward into the console, then adjusting the top plate so that the studs sit into the factory cut slots in the top of the safe assembly. (these slots are in both the front and back **2** in the front and **1** in the back)
6. Apply the **3 ACORN NUTS** provided by **LOCK'ER DOWN** to each of the **3** studs on the inside of the safe (these are the same studs that were thread through their respective slots in **Step 5**)
7. Insert the set screws into the sides of the safe using a 3/32 Allen wrench, **1** to each side of the safe
8. Tighten the set screws and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
9. Re-insert the padding that was removed from the safe before installation.
10. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH, 3/32 ALLEN WRENCH**
- 8mm Socket Bit or 3/32 Allen bit

Contents Included: **2** Set Screws

3 Acorn Nuts

