

LOCK'ER[®] DOWN



LD2072 Install
Video

INSTALLATION INSTRUCTIONS

LD2072/LD2072EX

[2019-2022 Chevrolet Silverado and GMC Sierra 1500, and 2021-2022
Chevrolet Silverado and GMC Sierra 2500, 3500]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the 2 File Holders on each side of the console compartment
 - a. Use a **T15 Torx Bit** to remove the 4 screws (2 to each side), then the file holders can be removed (this will be re-inserted, so retain these pieces)
4. Remove the **2** 11mm bolts from the bottom of the console compartment.
5. Remove the **2** side brackets from the LD2072 safe
 - a. To do this, open the lid, then using a **PHILLIPS HEAD SCREWDRIVER**, remove the **4** screws (2 to each side), allowing for the brackets to be temporarily removed.
6. Remove the neoprene padding from the inside of the safe for now.
7. Set the safe into the center console.
 - a. To ensure the safe is inserted into the console correctly, make sure that the factory cut holes at the bottom of the safe line up with the bolt's holes from **Step 4**.
8. Insert the **11mm BOLTS** provided by **LOCK'ER DOWN** into the bolt's holes from **Step 4**, through the bottom of the safe.
9. Re-attach the **2** brackets removed from **Step 5**, making sure that the side is flush with the inside of the safe.
10. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
11. Re-insert the padding that was removed from the safe before installation.
12. Re-insert the file holders removed from **Step 3**.
13. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH, SCREWDRIVER**
- 11mm Socket bit, T15 Torx Bit

Contents Included: **2** 11mm Bolts.

