

LOCK'ER[®] DOWN

INSTALLATION INSTRUCTIONS

LD6040/LD6040EX

[2018-2022 Toyota Camry]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Remove the **4 Bolts** at the bottom of the console compartment.
4. Remove the neoprene padding from the inside of the safe for now.
5. Set the safe into the center console.
 - a. The front slots at the bottom of the safe should **LINE UP** with the factory holes in the console.
6. Secure the safe to the console compartment using the **4 11mm LONG BOLTS** provided by **LOCK'ER DOWN**.
7. Tighten the bolts and the acorn nuts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE**.
8. Re-insert the padding that was removed from the safe before installation.
9. Enjoy your purchase!

Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- 11mm Socket bit

Contents Included: 4 11mm Bolts.

