

# LOCK'ER<sup>®</sup> DOWN



LD6080 Install  
Video

## INSTALLATION INSTRUCTIONS

### LD6080/LD6080EX

[2018 to 2021 Volkswagen Atlas]

1. For any combination style lock, it is a good idea to set the combination before installing the safe. We recommend that the combination be set with the **DOOR OPEN** in order to test the lock combination effectively without locking yourself out.
2. Clear out the contents of the center console for now, including the factory mat at the bottom of the console.
3. Use the T30 Torque bit along with your fastening device to remove the **2** bolts at the bottom and toward the front of the console. Make sure to keep the 2 removed bolts.
4. Remove the padding from the bottom of the inside of the safe.
5. Set the safe into the center console.
  - a. The front slots at the bottom of the safe should **LINE UP** with the factory holes in the console.
6. Using your 10mm fastening device, insert the **LOCK'ER DOWN PROVIDED 10MM BOLTS** into the factory holes at the bottom of the safe (these holes should line up with the factory screw holes at the bottom of the compartment)
7. Tighten the bolts, **DO NOT OVER TIGHTEN, THIS COULD DAMAGE THE CONSOLE.**
8. Re-insert the padding that was removed from the safe before installation.
9. Enjoy your purchase!

### Tools Needed:

- **IMPACT DRILL** or **SOCKET WRENCH**
- T30 Torque Bit
- 10mm Socket bit

**Contents Included:** **2** 10mm Bolts.

