

HOW TO MEASURE FOR CURTAINS

1. Measure window width from outer edge to outer edge.



2. Measure stack width (how many inches beyond the window frame would you like the rod to extend on each side?)

Tip: We recommend adding 6-10 inches on each side if space allows for it. This will ensure that the windows have maximum exposure when the curtains are open and stacked on the sides.



3. Measure height from the outer edge of window frame to the floor.



4. Measure the height that will be between the curtain rod and the upper outer edge of window frame.

Tip: Although we recommend at least 4 inches, the higher the rod from the window the better. The ideal location of the rod would be 2-3 inches below the ceiling or the crown molding (if there is one). Hanging curtains high above a window can make a room feel taller and more spacious.

