



VIATERRA		
SR NO	COMPONENT	QUANTITY
1	BASE PLATE	1
2	TOP PLATE	1
3	BUTTON HEAD ALLEN BOLT M5 X 10 MM	4
4	SPRING WASHERS M5	4
5	ALLEN KEY 3 MM	1

INSTRUCTIONS

1. Remove the contents from the packing carefully, and check if all parts are as per the component list.
2. Put your bike on the main stand or on a paddock stand, and put the side stand out.
3. Apply Loctite on each bolt as well as the bolt holes on the base plate.
4. Loosely attach the base plate with the top plate/s using the bolts and the spring washers. Refer to above drawing.
5. Place the above part on the side stand on the bike. You might have to loosen or remove the bolts while doing this.
6. Once the base of the side stand is properly aligned with the milled cavity on the base plate, tighten the bolts little by little, & in sequence using the allen key provided.
7. **DO NOT TIGHTEN ONE BOLT FULLY AND PROCEED TO THE NEXT AS THIS WOULD NOT ALIGN THE TOP PLATE PROPERLY ON THE BASE PLATE.**
8. Check for any play on the side stand shoe once all bolts have been fully tightened.