



101

OVERSPRAY PRIMER



- ◆ ENHANCES ADHESIVE BOND
- ◆ IMPROVES ADHESIVE OPEN TIME
- ◆ INCREASES ABRASION RESISTANCE
- ◆ TEMPORARY WEAR SURFACE



101 OVERSPRAY PRIMER

101 OVERSPRAY PRIMER is used as a primer over Maxxon underlayment prior to installation of Merkrete's waterproof and crack isolation membranes under ceramic tile and stone. Porosity of the floor is a leading factor in the drying rate of adhesives. This porosity factor may reduce the effective adhesive open time. Application of 101 Overspray Primer will minimize the porosity factor.

SUITABLE SUBSTRATES:

- Mortar Beds
 - Ceramic Tile & Stone
 - Concrete
 - Concrete Masonry
 - Gypsum
 - Exterior grade plywood¹
- ¹interior applications

USES:

- Increase bond for Merkrete membranes
- Reduce water loss on most substrates
- Prepare substrates for Hydro Guard and Fracture Guard membranes
- Temporary wear surface for construction traffic

SUITABLE FLOORING TYPES:

- Carpet
- Wood/Laminate
- VCT
- Sheet vinyl
- Pavers
- Stone

APPROXIMATE COVERAGES	
Substrate	Coverage per Gallon
All listed	250 - 300 sq. ft., depending on conditions

ORDERING INFORMATION	
Item#	Size
1836	2-gallon pail
1837	5-gallon pail

PAREXUSA

Parex USA, Inc., a California Corporation

Corporate Office

2150 Eastridge Ave • Riverside, CA 92507

merkrete.com • 866-516-0061

Tech Support: 800-226-2424