

Remove Allen Head bolts in each clamp. Remove front cage bolts, <u>use caution, cage may be under tension.</u> Install provided bolts with spacers, fastening loosely for adjustments. Evenly position Intrusion bar on to roll cage tubing. Fasten both center clamp bolts on each side. Ensure Fitment, and install remaining bolts. fasten all bolts securely before use.

Factory UTV LLC ©2020 – Yamaha YXZ 1000 R (2016-2020+) Front Bumper Instructions v<sub>L0</sub> pg. 9

<u>2016-2018</u>

Models Vary slightly but use same installation method and mounting hardware.



## Yamaha YXZ 1000r (2016+)

