

Polaris RZR Pro R, Pro R4, Turbo R, R4 (2022+)

A-Arm Guard Installation Guide

Position A-arm Guard on to lower a-arm in between Factory "Weep Holes" or "Vent holes" in the bottom of the a-arm. Use Clamps to hold in place once positioned. Mark all holes in Each A-Arm (A) location. With either a marker or a punch. Drill A-Arm (A) locations, with an $13/64^{\text{th}}$ Drill bit. The steel is thick in these locations, Use of a $1/4$ -20 Tap Is Required. Install (5x) $1/4$ "-20 x 1" Counter Sunk Bolts, For Each A-Arm (A) location. *(Use of thread locking compound is recommended)

Fasten each bolt loosely to allow for adjustments, if it seems like it doesn't line up when fastening, back out bolts and tighten bolts incrementally in a pattern until all bolt heads are snug and flush.

Do not over tighten, do not "Strip" or "Pull" bolts through plastic.

The UHMW will form a tighter fit over time.
Ensure all bolts are fastened securely before use.

