

Contact Us: *FACTORY UTV LLC*

9237 Beatty Drive Sacramento, CA 95826

Phone : (916) 383-2730

E-mail : info@factoryutv.net

Go online: www.Factoryutv.net



FACTORY UTV

In Bed Spare Tire Mount Installation Guide

Can-Am Commander (-2014/2015)

Covers : 800 & 1000 Models




Can-Am Commander 1000/800 (-2014/2015)

In bed spare tire mount installation guide.

Installation will require drilling for self tapping bolt locations. Use caution while drilling, **Do not drill all the way through the bed, drill until rivet head comes loose or becomes removable.**


Use : #Nº7 (13/64th) drill bit, (one size above the commonly available 3/16th bit)

Fasten all bolts securely when complete, do not over tighten.



#1

- A.)** Carefully drill out 4x rivet locations, drill until rivet head becomes loose or removable. Do not widen holes. (these 4x locations will be used with self tapping bolts)
- B.)** Remove front tie down bracket, tilt bed to remove nuts and bolts. Bracket can be Re-installed with spare tire mount *Optional.
- C.)** Remove center 2x Allen head bolts from upper drivers side of bed, Allen head bolts are re-used in later steps.



#2

- A.)** Install in-Bed spare tire mount. install 4x self tapping bolts and washers in rear bracket. do nit over tighten self taping bolts.
- B.)** Tilt bed to Install 2x forward bolts, nuts, and washers. *Optional: Re-use tie down bracket over spare mount bracket. Fasten bolts securely



#3

- C.)** Re-install top 2x Allen head bolts in upper driver side bed location. Fasten bolts securely.

Ensure all bolts are fastened securely when complete, do not overtighten bolts.