

8014 Installation Instructions Counter Top Waste System

Cut opening in counter top in desired location (see installation specifications). Opening must be 13 ¼" X 10 ½" and the space below the cutout must be clear of obstruction for at least 12" below counter top.

Attach touch lift spring onto the lift mechanism (see FIG 1).

1. Be sure the spring is in the closed position.
2. Place the front of the spring housing down first, being sure the hook catches the mount base.
3. Push the back of spring housing down, until it "clicks" into place.

NOTE: If lift height adjustment is needed, turn the extension tip counter clockwise to lengthen; turn tip clockwise, to shorten.

Place 1/8" bead of silicone (supplied) on top of the counter top around the edge of the cutout. Install waste system into opening with the lift mechanism facing **forward**. Keep the waste system as far to the **BACK** of the opening as possible being sure the lift actuator lever moves freely without touching the front edge of the cutout.

Install thumb screws through mounting brackets (FIG. 2). Place brackets on studs and extend under counter top (FIG. 3). Secure with star washer and nut. **DO NOT OVER TIGHTEN!**

Lightly tighten thumb screws until they are contacting bottom of counter top and holding waste system snugly in place (FIG.3).

