



Palm Tree Manual

How to Mount a Palm Tree

Concrete Pad Requirements

10'H to 12'H: 36"x36"x8"D

14'H to 16'H: 40"x40"x12"D

Creating Your Pad

Build a simple wood frame to outline your hole. Set/level frame inside hole so that at least one inch of frame is above ground level. This will prevent water from pooling around the base of your piece. Use a 2x4 suspended across the frame to smooth or level your concrete.

Mounting Your Piece

Option 1

After 20-30 minutes of curing, place piece on concrete pad. Use hammer to tap 1/2-inch, 4"L Redhead anchors through holes in base into moist concrete until flush. Wait 7-10 days before tightening nuts on the anchor.

Option 2

Let concrete cure up to 48 hours. Using a hammer drill create hole in concrete pad. Using 1/2-inch, 4”L Redhead anchors secure piece to the concrete pad.

Note: Wood frame can be removed after concrete is dry

