

WSM Floating Hinge Installation Instructions



Tools needed: Two locking pliers (C style), felt tip marker, ¼" drill bit and drill

REAR HINGE (Double Bar)

Step 1: Position the rear hinge just under the lip of the middle section opposite the door. Make sure the mount plate will seat flat against the wall of the middle section.



Step 2: Using your locking pliers secure the hinge to the middle section. Make sure the hinge is level and parallel to the lip of the middle section.

Step 3: Drill two ¼" holes using the hinge as a template.

Step 4: Install the bolts, flat washers, lock washers and nuts.

TOP HINGE (Single Bar)

Step 1: Place lid on the smoker so the thermometer is facing away from the hinge and centered over the door.

Step 2: Insert the single bar into and between the rear hinge (double bar).

Step 3: Position the top hinge so the bottom of the hinge plate is even with the top lip of the middle section.



Step 4: Using your felt tip, mark the holes (2).

Step 5: Using your locking pliers, secure the top hinge to the lid and drill $\frac{1}{4}$ " holes.

Step 6: Install the bolts, flat washers, lock washers and nuts.

The photos show the proper placement of the hinge parts.

If you have any questions, please call us at 573-443-6117.

Thanks,
Mark & Ryan Hunsaker

