

Weber Smokey Mountain Clip Installation Instructions

As you are aware, Weber manufactures several WSM models. This being said, we decided to make a universal clip that can easily be bent with your thumb to fit your exact model. By following the instructions below, you can easily make the clip fit your model.



Step 1: Place pre bent clip so bottom retainer lip is firmly against the bottom bowl lip.



Step 2: While holding the clip in place, start bending the top part of the clip to wrap over the lower part of the mid section door opening.



Step 3: Finish bending the clip over.



Step 4:



Step 5: With the top part of the clip bent over, your clip is ready.



Finished Retainer Clip.

If you have any questions please email hunsakersmokers1@gmail.com or call (573) 443-6117.
Thank you for your business.