

# Quick Start Guide

Begin with clean: water, tub & filters

## BROMINE HOT TUB SUPPLIES KIT



1



### **Bromine 4-in-1 Test Strips:**

Tests water Total Bromine, Total Alkalinity (TA), pH, and Hardness. Fill the spa with fresh water, then test for TA, pH, and Hardness. Note results. Bromine is tested later.

2



### **Alkalinity & pH Up:**

Raises low pH and Total Alkalinity (TA). If TA tests below 80ppm, add 1 heaping capful per 400 gallons to raise in 10ppm increments. Circulate water 30 minutes, retest.

3



### **Alkalinity & pH Down:**

Lowers high pH and Total Alkalinity (TA). If TA tests above 120ppm, add 1 level capful per 400 gallons to lower in 10ppm increments. Circulate water 30 minutes, retest.

4



### **Calcium Hardness Booster:**

Raises low Hardness. If below 150ppm, 1 level capful in 400 gallons increases calcium about 10ppm. Pre-dissolving recommended. Circulate water 30 minutes, then retest.

5



### **Bromine Tablets:**

Slow-dissolving spa water sanitizer. For use in Floating Tablet Dispenser. Bromine level will be tested later with Bromine 4-in-1 Test Strips.

6



### **Floating Bromine Tablet Dispenser:**

Load with bromine tablets. Set release rate per directions. Place in spa. Test sanitizer level after 24 hours. Adjust to maintain 3 to 5 ppm bromine. Retest periodically.

7



### **Bromine Booster:**

Establishes an immediate bromide reserve at startup, before Bromine Tablets have had time to dissolve. Add 1 level capful per 100 gallons when spa is initially filled.

8



### **Oxy-Spa Chlorine-Free Shock:**

Helps to maintain water quality. Add 2 oz. (1 level capful) for up to 500 gallons spa water weekly.

9



### **Metal Stain Preventer:**

Prevents staining and corrosion from dissolved metals. Add bottle contents on startup and with each water change, per label directions.

10



### **Chitosan Natural Clarifier:**

Promotes crystal clear water naturally. Add 1 oz. at startup and weekly per 300-500 gallons.

11



### **ZorbO Oil Scum Absorber:**

Hi-tech polymer with flow-thru design wicks-up oily film and inanimate scum. Float in hot tub. Replace every 3 to 4 months.

(800) 823-3638 | [help@spadepot.com](mailto:help@spadepot.com)



KT1004Q