

BROMINE HOT TUB SUPPLIES KIT







Bromine 4-in-1 Test Strips:

Tests water Total Bromine, Total Alkalinity (TA), pH, and Hardness. Fill the spa with fresh water, then test for TA, pH, and Hardness. Note results. Bromine is tested later.






Alkalinity & pH Up:

Raises low pH and Total Alkalinity (TA). If TA tests below 80ppm, add 1 heaping capful per 400 gallons to raise in 10ppm increments. Circulate water 30 minutes, retest.





Lowers high pH and Total Alkalinity (TA). If TA tests above 120ppm, add 1 level capful per 400 gallons to lower in 10ppm increments. Circulate water 30 minutes, retest.



Calcium Hardness Booster:

Raises low Hardness. If below 150ppm, 1 level capful in 400 gallons increases calcium about 10ppm. Pre-dissolving recommended. Circulate water 30 minutes, then retest.



Bromine Tablets:

Slow-dissolving spa water sanitizer. For use in Floating Tablet Dispenser. Bromine level will be tested later with Bromine 4-in-1 Test Strips.



Floating Bromine Tablet Dispenser:

Load with bromine tablets. Set release rate per directions. Place in spa. Test sanitizer level after 24 hours. Adjust to maintain 3 to 5 ppm bromine. Retest periodically.



Bromine Booster: Establishes an immediate bromide reserve at startup, before Bromine Tablets have had time to dissolve. Add 1 level capful per 100 gallons when spa is initially filled.



Oxy-Spa Chlorine-Free Shock:

Helps to maintain water quality. Add 2 oz. (1 level capful) for up to 500 gallons spa water weekly.



Metal Stain Preventer:

Prevents staining and corrosion from dissolved metals. Add bottle contents on startup and with each water change, per label directions.



Chitosan Natural Clarifier:

Promotes crystal clear water naturally. Add 1 oz. at startup and weekly per 300-500 gallons.





ZorbO Oil Scum Absorber:

Hi-tech polymer with flow-thru design wicks-up oily film and inanimate scum. Float in hot tub. Replace every 3 to 4 months.

(800) 823-3638 | Mon-Fri 6 AM-5 PM Pacific



Rev. 10-03-22