

SALT WATER HOT TUB SUPPLIES KIT







Spa 6-in-1 Test Strips:

Tests water Total Alkalinity (TA), pH, Hardness, and Free Chlorine. Fill the spa with fresh water, then test for TA, pH, and Hardness. Note results for adjustments.






Alkalinity & pH Up:


Raises low pH and Total Alkalinity (TA). If TA tests below 80ppm, add 1 heaping capful per 400 gallons to raise in 10ppm increments. Circulate water 30 minutes, retest.





Lowers high pH and Total Alkalinity (TA). If TA tests above 120ppm, add 1 level capful per 400 gallons to lower in 10ppm increments. Circulate water 30 minutes, retest.





Raises low Hardness. If below 150ppm, 1 level capful in 400 gallons increases calcium about 10ppm. Pre-dissolving recommended. Circulate water 30 minutes, then retest.



Metal Stain Preventer:

Prevents staining and corrosion from dissolved metals. Add bottle contents on startup and with each water change, per label directions.



Chitosan Natural Clarifier:

Promotes crystal clear water naturally. Add 1 oz. at startup and weekly per 300-500 gallons.



Dead Sea Salts:

Pre-dissolve 2 lbs. salt per 100 gallons. Allow generator 24 hours to produce chlorine. Adjust timer to achieve 3-4 ppm Free Chlorine (max.) using Spa 6-in-1 Test Strips.





Salt Test Strips:

Tests water salinity. Maintain 2,000-3,000 ppm. Replenish salt in order to maintain salinity, if necessary. Refer to your chlorine generator manual.



Oxy-Spa Chlorine-Free Shock:

Helps to maintain water quality. Add 2 oz. (1 level capful) for up to 500 gallons spa water weekly.





ZorbO Oil Scum Absorber:

Hi-tech polymer with flow-thru design wicks-up oily film and inanimate scum. Float in hot tub. Replace every 3 to 4 months.





Acid Magic:

Use diluted for cleaning chlorine generator cell scale. Inspect cell every 3 months. Follow maintenance directions provided with Saltron Mini or other salt system.

(800) 823-3638 | Mon-Fri 6 AM-5 PM Pacific



Rev. 10-03-22