



Function7 Billet Aluminum Rear Subframe Brace

For 92-95 Civic, 92-97 Del Sol, & 94-01 Integra (Excluding Type-R)

Part #: F7EGBR

Thank you for choosing Function7 Products!

All Function7 Rear Subframe Braces include all necessary hardware for a seamless installation. While we do the utmost to ensure quality checks, please inspect all parts before installation. Please clean all vehicle mounting points to ensure proper fitment and prevent possible seizing. Always do a mock fitment test before completely torquing down the bolts to alleviate any alignment imperfections.

Installation Instructions:

1. Align the brace with your LCA bolts.
2. Insert M10x90mm Subframe/LCA Bolts
3. Line up Left and Right side backings
4. Insert M8x55mm (top) & M8x45mm (bottom) Bolts
5. If installing a sway bar, use the supplied 20mm Bolts for D-bracket installation

Package Contents:

- x1 Billet 6061-T6 Aluminum Rear Subframe Brace
- x2 M10 x 90mm Flange Bolts
- x2 M8 x 55mm Flange Bolts
- x2 M8 x 45mm Flange Bolts
- x2 M8 x 20mm Flange Bolts
- x2 M8 Nuts
- x2 M10 Washers
- x2 M8 Washers
- x1 Left Side Backing
- x1 Right Side Backing
- x1 Function7 Decal



www.function7.com

For questions and/or concerns, please email us at : info@function7.com