



Function7 Billet Aluminum Rear Subframe Brace

For 96-00 Civic

Part #: F7EKBR

Thank you for choosing Function7 Products!

All Function7 Rear Subframe Braces include all necessary hardware for a seamless installation. While we do the utmost to ensure quality checks, please inspect all parts before installation. Please clean all vehicle mounting points to ensure proper fitment and prevent possible seizing. Make sure to wipe down any residue left over from the machining process and always do a mock fitment test before completely torquing down the bolts to alleviate any alignment imperfections.

Installation Instructions:

1. Align the brace with your LCA bolts.
2. Re-using the existing bolts, insert the Subframe/LCA Bolts
3. Line up Backings
4. Insert M8x45mm (top) & M8x25mm (bottom) Bolts
5. If installing a sway bar, use the supplied 20mm Bolts for D-bracket installation

Package Contents:

- x1 Billet 6061-T6 Aluminum Rear Subframe Brace
- x2 M8 x 45mm Flange Bolts
- x2 M8 x 25mm Flange Bolts
- x2 M8 x 20mm Flange Bolts
- x2 Backings
- x1 Function 7 Decal



www.function7.com

For questions and/or concerns, please email us at : info@function7.com