

Toilet Guide

The following is a guide for the recommended set outs when installing code bathroomware toilets.

PURE OVERHEIGHT BTW TOILET SUITE

1. 50-150
2. 95-190 (included)
3. 135-245



FLOW OVERHEIGHT BTW TOILET SUITE

1. 70-80
2. 90-180 (included)
3. 145-235



FLOW INWALL TOILET PAN

1. 100-140
2. 90-120 (included)
3. 140-190



PURE INWALL TOILET PAN

1. 60-90
2. 95-125 (included)
3. can not be used



PURE BTW TOILET SUITE

1. 70-120
2. 80-180 (included)
3. 140-220



FLOW BTW TOILET TOILET SUITE

1. 60-180
2. 120-220 (included)
3. 145-220



PURITY BTW TOILET SUITE

1. 60-90
2. 95-170 (included)
3. 140-220

