Instruction Sheet

OFFROAD TECHNOLOGY





Wire Color	Power	Function 1
Red	+12VDC Trigger #1	Projection Beam - White
White	+12VDC Trigger #2	NOT USED
Black	-12VDC Shared ground	Ground

В

Bracket to Light Steps

Push the plastic mount bushings ${f C}$ into lamp

1. housing; fits between mounting bracket and housing.

Align mounting bracket **D** to lamp; bracket

can be flipped either direction based on mounting application.

Insert (2) mounting bolts A with (4) flat washers

- **3. B** and (2) nylock nuts **F** as shown; Final torque once aimed properly.
- 4. Insert 3/8" mounting bolt through mounting bracket and secure using (2) flat washers, (1) lock washer, & (1) standard nut **E**.
- **5.** Aim lamp properly prior to final torque.
- 6. Please use the provided thread lube on mounting bolts A prior to installing the nuts.
- 7. Post your new set up, tag @thenachoexperience and enjoy!

