

## INSTRUCTION SHEET



# BEAT THE HEAT FOR INDIAN BIG-TWIN MODELS


### INCLUDED COMPONENTS:

- Pre-cut Dynamat Xtreme

### HELPFUL FOR INSTALLATION:

- Dynamat Roller
- Gloves

### QUESTIONS?

-  **EMAIL:**  
info@getklocked.com
-  **CALL:** (605) 996.3700

1



3



2



4



5



1. Protect painted surfaces
2. Remove the seat (**Fig 1**)
  - a. Remove the bolt in the rear fender
  - b. Remove the top left and right-side covers
  - c. Remove the seat bolts with a 6mm Allen wrench
3. Turn the seat over and clean the pan with a soft cloth (**Fig 2**)
4. Remove the paper backing from the Dynamat (**Fig 3**)
5. Line up the hole in the Dynamat with the hole in the seat pan as shown (**Fig 4**)
6. Rub the Dynamat with a cloth to set the adhesive (**Fig 5**)
  - a. Take care and use a cloth so reduce the risk of injury from the foil lining
7. Once the Dynamat is set, install you seat and enjoy a cooler ride! (**Fig 6**)

6



**CAUTION:** Klock Werks cannot be held responsible for any damage to painted surfaces during removal or addition of Klock Werks parts.