

INSTRUCTION SHEET



BMW FLARE™ WINDSHIELD

FOR 2011+ BMW K 1600 GT, GTL, B, GRAND AMERICA

INCLUDED IN BOX:

- (1) Flare™ Windshield
- (1) Instruction Sheet

TOOLS NEEDED:

- + T25 Torx Driver

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Protect all painted surfaces.
2. Remove both screws and trim from the right hand side.
3. Temporarily replace top screw through windshield to help hold it in place
4. Remove both screws and trim from the left hand side.
5. Remove top right hand screw and windshield.
6. Place new windshield on, making sure that the center hole on the left and right are lined up with the aligner on the bracket.
7. Temporarily install the top right hand screw through the windshield.
8. Install the left hand trim and both screws but do not tighten.
9. Remove top right hand screw.
10. Install right hand side trim and both screws.
11. Tighten all four screws.
12. Clean with Shine Werks and enjoy!

WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192