



## FLARE™ WINGS FOR INDIAN CHALLENGER

### INCLUDED COMPONENTS:

- Flare™ Wings
- Installation Instructions
- Alcohol Wipes

### QUESTIONS?



EMAIL:  
info@getklocked.com  
CALL: (605) 996.3700



1. Test fit Flare® Wing to the fairing aligning the front edge of the Flare® Wing to the front edge of the fairing mounting surface (Fig 1)  
**NOTE:** We suggest applying masking tape to surrounding areas to prevent accidental application of primer to non-mating surfaces
2. Clean the mating surface with supplied alcohol wipes (FIG 2)
3. Allow surface to dry completely and keep free of contaminants
4. Crush at dot ● on M3 Primer 94 and apply a thin coat to all mating surfaces (FIG 2)
5. Allow to dry for a minimum of 5 minutes but no more than 45 minutes



6. Remove the liner from the four pieces of adhesive (Fig 3)
7. Carefully place the Flare® Wing in position as you had test fit (Fig 4)
8. Press the Flare® Wing to the fairing with firm pressure along the outer edge working all the way around perimeter multiple times (Fig 5)  
**NOTE:** Watch the gap between the Flare® Wing and fairing as you apply pressure to verify compression of the adhesive (Fig 6)
9. It is recommended to wait a minimum of 24 hours after installation before operating the motorcycle with full cure of the adhesive at 72 hours

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.