

INSTRUCTIONS



FLARE™ WINDSHIELD FOR WEDGE FAIRING

INCLUDED COMPONENTS:

- Flare™ Windshield
- Installation Instructions

TOOLS NEEDED:

- 5/32" Allen Wrench
- 7/16" Wrench
- Shine Werks

QUESTIONS?



EMAIL:
info@getklocked.com
CALL: (605) 996.3700



1. Using a 5/32" allen wrench and a 7/16" wrench, remove all 5 windshield bolts (FIG 1).
 - a. Remove center bolt last to reinsure your windshield doesn't fall.
2. Gently remove your windshield (FIG 2).
3. Install your new Klock Werks Flare™ Windshield by reusing the windshield bolts (FIG 3).

NOTE: Be mindful not to over-tighten the windshield hardware.
4. Using your Shine Werks, give the windshield and fairing a good wipe down and enjoy the ride (FIG 4).



WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192