



FLARE™ WINDSHIELD FOR H-D FLH



EMAIL:
info@getklocked.com



CALL:
(605) 996-3700



1. Remove the three windshield mounting bolts on the top of the fairing, and remove your stock windshield

NOTE: Gently pushing the windshield forward from behind the center screw may aid in removal.



2. Install the outer two mounting bolts loosely



3. Guide an end of your new Klock Werks Flare™ down onto one of the outer mounting bosses



4. Guide the opposite end of the Flare™ down onto the other outer mounting boss



5. Gently guide the center of your Klock Werks Flare™ over the center mounting boss and start the center mounting screw by hand



7. Secure the windshield mounting hardware, making sure that the Flare™ is resting on the mounting bosses and not on the mounting screw to avoid pinching



CORRECT



INCORRECT

* A misaligned or incorrectly installed windshield, can cause damage around the mounting hole.

WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.