

## CUSTOMER COPY



### FLARE™ WINDSHIELD FOR INDIAN CHIEFTAIN

EMAIL:  
info@getklocked.com

CALL:  
(605) 996-3700



1. Raise your windshield all the way up.



2. Remove all 5 mounting screws and square nuts.



**TIP:** You can place low-tack tape on the back of the square nuts and bracket to help prevent them from falling into the fairing.



4. Install your new Flare™ Windshield and torque fasteners to factory specifications.

**WARNING!** Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192