



FLARE™ WINDSHIELD FOR PAN-AMERICA

INCLUDED COMPONENTS:

- Flare™ Windshield
- Hardware
- Installation Instructions

TOOLS NEEDED:

- T25 Torx
- Shine Werks

QUESTIONS?

- EMAIL: info@getklocked.com
- CALL: (605) 996.3700

1. Using T25 Torx, remove the four screws from the windshield (Fig 1)

NOTE: Support the vent and windshield when removing the screws to prevent the vent from falling (Fig 2)



2. Using included screws and washers, install your Klock Werks Flare™ (Fig 3)

NOTE: Make sure the vent remains over the mounting bosses as you tighten to the factory recommended torque value (Fig 4)

3. Use your Shine Werks for a final wipe down and enjoy the ride! (Fig 5)



WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192