

## INSTRUCTIONS



# FLARE™ WINDSHIELD FOR POLARIS SLINGSHOT

### INCLUDED COMPONENTS:

- (1) Flare™ Windshield
- (1) Installation Instructions

### TOOLS NEEDED:

- T27 Torx Driver

### QUESTIONS?



EMAIL:  
info@getklocked.com  
CALL: (605) 996.3700



1. Protect all painted surfaces.
2. Open the hood.
3. Remove two outside Torx head screws (FIG 1).
4. If your Slingshot has a center post, remove the Torx head windshield screw from the top. This screw will not be reused and the center post is no longer needed for support.
5. If your slingshot has a screw in the center tab at the bottom of the windshield, remove it (FIG 2).
6. Remove your windshield by rotating the top forward slightly and pulling the tabs out of the dash.
7. If your current windshield did not use a center screw at the bottom, locate and verify that a well nut is installed in the dash. **There may be plastic plug in the mounting hole that needs to be removed to install the wellnut.**

### Note: Polaris Hardware Part Numbers:

- a. Screw, M6 x 25, Part 7520239
- b. Washer, Rubber, Part 5410609
- c. Wellnut, 6mm x 1.0mm, Part 7547772



8. Insert the tabs of your new Klock Werks Flare™ into the dash and set it into place (FIG 3).
9. Reinstall the factory screws into the three holes along the bottom and torque to 9 in-lbs.

**WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.**

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192