

# CUSTOMER COPY



## FLARE™ FOR YAMAHA STRATOLINER



EMAIL:  
info@getklocked.com



CALL:  
(605) 996-3700

1. Loosen the four windshield trim fasteners and remove the trim and the stock windshield
2. Clean the trim and fairing of any loose dirt to prevent scratching
3. Install your new Flare windshield with the hardware and trim removed in step 1 and torque to factory specification



CORRECT



INCORRECT

\* A misaligned or incorrectly installed windshield, can cause damage around the mounting hole.

**WARNING!** Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192