



FLARE™ WINDSHIELD FOR VICTORY



EMAIL:
info@getklocked.com



CALL:
(605) 996-3700



1. Using a 4mm Allen wrench, remove the four fasteners that hold the stock windshield to the mount brackets.

NOTE: For installation on the Cross Country Tour, the Touring windshield brackets and the rubber support strips between the front and inner fairings need to be removed.



2. Remove the stock windshield and replace it with the new Klock Werks Flare Windshield. Align the holes in the windshield to the mount points on the windshield brackets.



3. Carefully install the hardware removed in step 1 and torque them evenly to 18-20 in-lbs

WARNING! Using Loctite® or any type of thread locker on hardware will result in breakdown of the Polycarbonate and cause cracking.

Klock Werks cannot be held responsible for any damage resulting from improper installation performed by any consumer or their dealer.

U.S. Pat. No. D586,274; D632,235; D586,275; D633,017; D626,046; D633,018 Pat. 001050165-0001, 001050165-0002, 001050165-0003 APO No. 324093, 324094, 325192