



UTV FLARE™ 2018+ TEXTRON WILDCAT XX

TOOLS NEEDED:

- Rubber Mallet
- Shine Werks™

INCLUDED COMPONENTS:

- (1) UTV Flare™ Windshield
- (4) Axia Clamp Kits
- (1) Trim Kit

QUESTIONS?

- ✉ EMAIL: info@getklocked.com
- ☎ CALL: (605) 996-3700



1. Remove the thumb screws, rubber washers, and nylon washers from the pre-assembled j-hook clamps. (Fig 1)
2. Place the nylon washer onto the stud of the j-hook clamp. (Fig 2)
3. After inserting the j-hook stud into the windshield holes from the rear side, reinstall metal/rubber washers onto stud with rubber facing and windshield. (Fig 3)
4. Install thumbscrew onto j-hook clamp. (Fig 4)



5. Three pieces of trim are provided for the major contact points of the windshield onto the body. (Fig 5)
6. Be sure that trim is firmly secured prior to installing windshield onto your machine.
7. Install UTV Flare™ Windshield onto machine with j-hooks partially unthreaded, and rotated to clear the roll bars.
8. Rotate j-hooks perpendicular to bar and tighten.
9. Clean with Klock Werks Shine Werks, the recommended and safe cleaner for your UTV Flare™ Windshield.