



Grenadier Fender Plate Installation

This Installation Guide will help you mount your new GP Factor Fender Plates for the Ineos Genadier.

***GP FACTOR DOES NOT WARRANTY INSTALLATION OF THIS KIT. IF YOU ARE NOT FAMILIAR OR SKILLED WITH INSTALLATION OF PARTS ON YOUR VEHICLE, WE RECCOMEND HAVING A QUALIFIED GP DEALER INSTALL FOR YOU.**

STEP 1: Insure the surface is properly clean and free of dirt or any other grime. After the fender surface is clean, using a clean cloth, rub the surface with alcohol to insure a completely clean surface that will allow for adhesion of the VHB tape fully.

STEP 2: The fender plates have the 3M VHB tape already installed on the plate for you. We reccomend peeling back the VHB at the corners of each section and having the red film tabs exposed as you line up and install your fender plate. This is make installation easier and allow you to make easier adjustments as you install. ****DO NOT PEEL THE VHB FULLY AND PLACE DOWN ON YOUR FENDER. THIS VHB IS EXTREMELY STRONG AND WILL MAKE IT NEXT IMPOSSIBLE TO MOVE IF YOU DID NOT LINE IT UP CORRECTLY.**



STEP 3: Place your Fender plate on the clean surface of your fender, insuring it is lined up in the position that you want it with the red film tabs exposed. **DO NOT** press down heavily on the plate as you are lining it up and using the exposed tape sections to hold it in place.





FACTOR

Grenadier Fender Plate Installation

STEP 4: Once you have your fender plate in the position you want it, carefully pull the red film away one section at a time, ensuring your fender plate stays in the same location. After the sections of film are removed, you can apply pressure to ensure your VHB has begun to adhere to your fender.



STEP 5: 3M VHB needs at least 12-24 hours to bond properly for the adhesion to work. Please avoid driving for 24 hours or exposing the fender plate to the elements. Please reference the 3M VHB Technical Data sheet for more information. Full Bond is in 72 hours if installed correctly.

<https://multimedia.3m.com/mws/media/23664870/3m-vhb-tape-5952.pdf?&fn=3M-VHB-Tape-5952.pdf>

