



Ford Bronco High Clearance Crash Bars Installation Instructions

Thank you for purchasing our Ford Bronco High Clearance Crash Bars!

Installation Notes:

- These brackets are not compatible with the factory steel bumper.
- This kit will come with new hardware, if you are replacing the factory crash bars, the factory hardware can be reused.

Tools required:

- Jack and Jack Stands
- 18mm Socket and Ratchet
- 16mm Socket and Ratchet
- Phillips Head Screwdriver

Contents of each box

Bill Of Materials For B4WK12776 Ford Bronco High Clearance Crash Bars with Hardware			
QTY	Part Number	Etch Number	Description
2	B4WK12768P	N/A	Ford Bronco High Clearance Rear Crash Bar
1	B4WK12769P	N/A	Ford Bronco High Clearance Front Pass. Crash Bar
1	B4WK12770P	N/A	Ford Bronco High Clearance Front Driver Crash Bar
8	.120C800BHF1Z/6921	N/A	M12-1.75 X 80 Hex Flange Bolt 10.9 Zinc



Step 1:

Jack the front of the vehicle up and set it on jack stands. Ensure the vehicle is safe and stable. Remove the front tires from the vehicle. If you have factory crash bars already installed, you may have to remove your front bumper to fully remove the crash bars in the front.

Step 2:

If you have factory front crash bars installed, use the 18mm socket to remove them from both sides of the vehicle.

Step 3:

Slide in the new High Clearance Crash bars with the opening facing the rear of the vehicle. If reusing the factory hardware, use the 18mm socket and fully tighten the hardware. If you are using the provided M12 hardware, use the 16mm socket and fully tighten the hardware. If removed, you can reinstall the front bumper now.



Step 4:

If you have the factory rear crash bars installed, use the 18mm socket to remove them from both sides of the vehicle. It may be necessary to move the inner fender liner out of the way to fully remove the rear bolts.



Step 5:

Slide in the new High Clearance Crash bars with the opening facing the front of the vehicle. If reusing the factory hardware, use the 18mm socket and fully tighten the hardware. If you are using the provided M12 hardware, use the 16mm socket and fully tighten the hardware.



Congratulations! You have completed the installation of the Barnes 4WD Ford Bronco High Clearance Crash Bars!

Professional Services Disclaimer:

The content of all pages of this website (collectively, the "Website"), such as text, graphics, images, information and other material (collectively, "Content") is for informational purposes only. Any information furnished on this Website is not intended nor implied to be automotive advice and is not intended to replace personal consultation with a qualified automotive service technician, mechanic, or similar automotive professional.

Barnes 4WD has not examined the Content for accuracy, timeliness, completeness, appropriateness, or helpfulness. Barnes 4WD does not endorse any specific tests, products, procedures, opinions, or other information that may be mentioned on this Website. Your reliance upon information and Content obtained by you at or through this Website is solely at your own risk. IN NO EVENT SHALL BARNES 4WD BE LIABLE OR OTHERWISE RESPONSIBLE FOR ANY DAMAGE OR INJURY (INCLUDING DEATH) TO YOU, OTHER PERSONS, OR PROPERTY ARISING FROM ANY USE OF ANY PRODUCT, INFORMATION, IDEA, OR INSTRUCTION CONTAINED IN THE CONTENT.

BARNES 4WD DOES NOT MAKE ANY REPRESENTATION OR WARRANTY, EXPRESS OR IMPLIED, AT LAW OR IN EQUITY, WITH RESPECT TO ANY PRODUCT FEATURED ON THE WEBSITE, INCLUDING WITHOUT LIMITATION WITH RESPECT TO MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, VALUE, VALIDITY, OR ENFORCEABILITY, AND ANY AND ALL SUCH OTHER REPRESENTATIONS OR WARRANTIES ARE HEREBY EXPRESSLY DISCLAIMED.