



Ford Bronco Dual ARB Mounting Bracket Installation Instructions

Thank you for purchasing this product!

Installation Notes:

- This kit is designed to fit 2021 to current Bronco 2 door or 4 door with the 2.7 or 2.3 engine
- This kit will not fit Bronco sport models
- This will not fit Raptor or Everglades models
- May not be compatible with some aftermarket air intakes or turbo piping
- Consult a factory service manual for removal of any OEM components
- 2 90° fittings have been included in this kit, but will generally only be used if installing the ARB manifold (see last image for orientation of fittings and hose).
- Pipe sealant is recommended for any NPT threads
- This mount is designed to work with an ARB high performance twin on-board compressor Part# CKMTA12 and optional air locker manifold kit Part# 171503

Tools required:


- 10mm Socket
- 10mm Wrench
- 9/16" Wrench
- 8mm Socket
- 15mm Deep well socket
- Ratchet
- Extension

Contents of kit

Bill Of Materials For B4WK12781			
QTY	Part Number	Etch Number	Description
2	9250144	NA	JIC 4M x 1/4 NPTM 90 Elbow
1	B4W125150P	NA	Bronco Dual ARB Mount Powder Coated
1	B4W125151P	NA	Bronco Dual ARB Mount Support Powder Coated



Step 1:

Install the compressor and manifold (if used) to the mounting bracket using the hardware supplied from ARB. Only install 2 bolts in the outer holes for the compressor.




Step 2:

Remove the nut that is closest to the engine on the right front strut. Place the support bracket over the stud and install the nut, but do not tighten.




Step 3:

Remove the bolt that attaches the ground strap, and the 2 bolts that attach the computer bracket to the inner fender structure. Lift the computer up and out to disengage the tab holding it to the inner fender structure.



Step 4:

Install the bracket-compressor assembly over the computer and mounting bracket, the tab on the bracket should be sandwiched between the inner fender structure and the computer bracket. Install the 2 bolts removed from the computer in step 3 but do not tighten.



Step 5:

Install the 2 bolts (supplied with ARB compressor) from underneath through the support bracket and into the bottom of the compressor.

Step 6:

Reinstall the ground wire and bolt removed in step 3 and tighten all hardware. Close the hood gently to check for any interference, repositioning of some plumbing may be required for optimal hood clearance.

Congratulations installation is complete!

Professional Services Disclaimer:

The content of all pages of this website (collectively, the "Website"), such as text, graphics, images, information and other material (collectively, "Content") is for informational purposes only. Any information furnished on this Website is not intended nor implied to be automotive advice and is not intended to replace personal consultation with a qualified automotive service technician, mechanic, or similar automotive professional.

Barnes 4WD has not examined the Content for accuracy, timeliness, completeness, appropriateness, or helpfulness. Barnes 4WD does not endorse any specific tests, products, procedures, opinions, or other information that may be mentioned on this Website. Your reliance upon information and Content obtained by you at or through this Website is solely at your own risk. IN NO EVENT SHALL BARNES 4WD BE LIABLE OR OTHERWISE RESPONSIBLE FOR ANY DAMAGE OR INJURY (INCLUDING DEATH) TO YOU, OTHER PERSONS, OR PROPERTY ARISING FROM ANY USE OF ANY PRODUCT, INFORMATION, IDEA, OR INSTRUCTION CONTAINED IN THE CONTENT.

BARNES 4WD DOES NOT MAKE ANY REPRESENTATION OR WARRANTY, EXPRESS OR IMPLIED, AT LAW OR IN EQUITY, WITH RESPECT TO ANY PRODUCT FEATURED ON THE WEBSITE, INCLUDING WITHOUT LIMITATION WITH RESPECT TO MERCHANTABILITY, FITNESS FOR ANY PARTICULAR PURPOSE, VALUE, VALIDITY, OR ENFORCEABILITY, AND ANY AND ALL SUCH OTHER REPRESENTATIONS OR WARRANTIES ARE HEREBY EXPRESSLY DISCLAIMED.