



987/BOXSTER and CAYMAN POLYURETHANE SIDE SKIRT INSTALLATION INSTRUCTIONS

- o Remove rear rocker panel wedge at end of rocker panel in front of rear wheel**
- o Remove 3 screws from wedge**
- o Side skirts are attached at each end and underside with screws and clips provided**
- o Use quick drying bonding adhesive or 2 sided tape with an accelerator to attach side skirts to body**
- o The top of the side skirt is designed to fit where the rocker panel comes to a point.**

FIT PARTS BEFORE PAINTING

URETHANE PAINTING INSTRUCTIONS

- 1. Fill all slight imperfections, if applicable, with a flexible putty and sand smooth.**
- 2. Clean surface with acetone on a clean cloth and wipe down the entire part.**
- 3. Put Comet or scouring cleanser on moistened green Scotch pad and go back and forth until water does not bead on the part.**
- 4. Apply adhesion promoter or equivalent Dupont #2322.**
- 5. Please note that some painters prefer, after cleaning the surface, to apply Dupont "Variprime".**
- 6. Apply basecoat/clearcoat following manufacturers recommendations for painting flexible polyurethane plastic.**

We always recommend that you fit parts before prep and paint