



987 POLYURETHANE FRONT SPOILER INSTRUCTIONS

**We recommend using bonding adhesive
rather than 2-sided tape.**

FIT PARTS BEFORE PAINTING (Removal of OEM side splitters required)

URETHANE PAINTING INSTRUCTIONS

1. Fill all slight imperfections, if applicable, with a flexible putty and sand smooth.
2. Clean the surface with acetone on a clean cloth and wipe down the entire part.
3. Put Comet or scouring cleanser on moistened green Scotch pad and go back and forth until water does not bead on the part.
4. Apply adhesion promoter or equivalent Dupont #2322.
5. Please note that some painters prefer, after cleaning the surface, to apply Dupont "Variprime".
6. Apply basecoat/clearcoat following manufacturers recommendations for painting flexible polyurethane plastic.

****Consult your local paint supplier for best materials to use in your area**

****Consult your local paint supplier for best materials to use in your area****