

BOXSTER/CAYMAN R WING

987/986 Boxster/Cayman

Installation Instructions

- Fit and adjust
- The back of the leg supports should be approximately $\frac{3}{4}$ "-1" from the end of the hatch cover.
- The OE rear spoiler can function or be deactivated – whichever you prefer. See instructions below to deactivate spoiler.

DEACTIVATION OF SPOILER CONTROL

Option 1 – Without Porsche Diagnostic Tool

- Open protective cover on the back side to the rear spoiler
- Pull off plug of the electrical propulsion of the original rear spoiler
- Connect the white/brown wires with the brown wire with wire connector or tape

Option 2 – Using Porsche Diagnostic Tool

- Diagnostics
- Choose Vehicle Type: 987
- Control Module: Rear
- Coding
- Spoiler Function Active: Choose "NO"

Option 3

- Unplug cable in rear under carpet to the left of the lock
– it's the 5 point plug







PREPPING INSTRUCTIONS FOR FRP PARTS

****Fit parts before prep and paint****

Our NR Automobile body parts come with a sealer poly primer. This primer will fill in any small pinholes that may be present. Parts need to be sanded before painting and may require another primer coat before painting. Do not bake parts during the painting process.