



#99612

SIDE SKIRT INSTALLATION INSTRUCTIONS

- **Remove rear rocker panel wedge at end of rocker panel in front of rear wheel**
- **Remove 3 screws from wedge**
- **Side skirts are attached at each end and underside with screws and clips provided**
- **Use quick drying bonding adhesive to attach side skirts to the body.**
- **We manufacture our side skirts with more material at each end to allow for any grinding that may be necessary for fitment**

We always recommend that you fit parts before prep and paint

FIT PARTS BEFORE PAINTING

URETHANE PAINTING INSTRUCTIONS

1. Fill all slight imperfections, if applicable, with a flexible putty and sand smooth.
2. Clean surface with acetone on a clean cloth and wipe down the entire part.
3. Put Comet or scouring cleanser on moistened green Scotch pad and go back and forth until water does not bead on the part.
4. Apply adhesion promoter or equivalent Dupont #2322.
5. Please note that some painters prefer, after cleaning the surface, to apply Dupont "Variprime".
6. Apply basecoat/clearcoat following manufacturers recommendations for painting flexible polyurethane plastic.

****Consult your local paint supplier for best materials to use in your area**