



## 997 SIDE SKIRT INSTALLATION INSTRUCTIONS C2/C4S/Turbo

**We always recommend that you fit parts before  
prep and painting**



- Remove mud guard wedge at rear end of original rocker
- We manufacture our side skirts with more material at each end to allow for any grinding that may be necessary for fitment
- Due to the nature of material used for our side skirts, we recommend that you set them in the sun for a while so that they become more flexible for ease of installation
- Side skirts are attached at each end and underside with screws and clips provided
- Use quick drying bonding adhesive to attach side skirts to body

### PREPPING INSTRUCTIONS FOR FRP PARTS

Our NR Automobile body parts come with a sealer poly primer. This primer will fill in any small pinholes that may be present. Parts need to be sanded before painting and may require another primer coat before painting. Do not bake parts during the painting process.

**NR Automobile Accessories**

