



1959-1966 C-10 and GMC Billet Tailgate Latches

CNC machined out of 6061 Billet Aluminum with stainless steel hardware.

Use cutting fluid when tapping and drilling holes.

Tools needed: 1/2-13 tap, tap handle or tap socket, 1/2" drill bit or step bit and drill.

Slotted for variations in trucks

Tap bedside to 1/2-13 threads

Drill tab out to 1/2"



Use anti-seize or axle grease on shoulder bolt for smooth operation.

A lanyard or key ring can be added to the pins if desired.

Use a little bit of Loc-Tite on the threaded receptacles on final installation.

You may need to tweak the tabs on tailgate for better alignment.

Cerakote or Anodizing are the preferred coatings. Powder coat and paint will be too thick and may hinder operation.

