



Twist Dynamics Hood Vent/Clear Hood Vent Installation Instructions

Tools needed: T-20 Allen Wrench, 4 screws, 1 Large Spacer, 1 Small Spacer



Step 1: Remove stock hood vent by unclipping the two clips directly underneath the hood.
*Replace with screws and spacers, facing upwards



Step 2: Place Hood Vent over the spacers.





Step 3: Place screws in holes.



Step 4: Proceed to screw in 2 remaining screws.



Step 5: All done!



If you have any questions, comments, or concerns about this product, please contact Twist Dynamics directly at: (941) 323 – 5912 or email: sales@twistdynamics.com and we will be happy to help.