

Designed by Jacques Adnet

PRODUCT



COLOURS



Item no.: 61045-XX
+ style code

DESCRIPTION

Few designers have succeeded in making a mirror a design icon but Jacques Adnet was the exception. Today, the elegant leather mirror that Adnet designed in 1950 provides inspiration for designers all over the world. His style is the epitome of luxury, so his 1950's collaboration with the exclusive French fashion house Hermès was a natural. In association with Hermès, Adnet developed a Collection of discreet yet voluptuous leather-covered furniture and interior accessories. This distinctive, round leather mirror with equestrian inspired detailing is a perfect example of Adnet's designs at that time. The mirror is available in either black, olive green or brown leather with strap and in three sizes: Ø45, Ø58 and Ø70 cm. The length of leather strap that supports the mirror is in direct proportion to the mirror diameter.

VERSION

- Tan Full Grain aniline leather / mirror glass
- Black Full Grain aniline leather / mirror glass
- Olive Full Grain aniline leather / mirror glass

MIRROR VERSION

Series contains the following:

Ø45, Ø58, Ø70



ACCESSORIES

Adnet hanging - Brass - Order item no.: 61000-99050

FACTS

MEASUREMENT

H: 90 X Ø45 cm
Depth of mirror frame: 7 cm
Strap width: 2.3 cm
Leather thickness frame 4,5 x two layers: 9 mm
Leather thickness strap: 4,5 mm
Mirror glass 4mm according to EN 1036-2

WEIGHT ITEM

3,9 kg

PACKAGING TYPE

Cardboard box

PACKAGING MEASUREMENT - L X W X H CM

L:60 W:60 H:13,5 CM

WEIGHT PACKAGING - MATERIAL TYPE

- Delivery note: 10 g
- Certificate: 10 g
- Assembly instructions: 10 g
- Bubble postal bag: 10 g
- PE polybag: 5 g
- Mounting parts: 45 g
 - Bracket: Burnished brass
 - Drywall plug Driva TP12
 - Hanger bolt
 - Hexalobular socket key
 - Tack-It removable adhesive
 - Nylon dowel 8X40 mm
- Cardboard box outer packaging quality ---: 940 g
- Cardboard box inner packaging quality ---: 710 g
- Polystyrene EPS foam: 450 g

WEIGHT PACKAGING - TOTAL

6 kg

NUMBER OF PARCELS

1 pcs.

ADNET CIRCULAIRE SMALL // GLASS MIRROR

ADNET COLLECTION

Designed by Jacques Adnet CLEANING AND MAINTENANCE

For normal cleaning, vacuum or dust frequently with a clean, dry cloth. If leather is soiled, it can be wiped with a damp soft cloth and a lather of any mild soap and a minimum amount of lukewarm water. Do not spot clean leather; clean the entire surface. Wipe clean with a damp cloth and dry with a clean, soft cloth. For spots and spills, wipe excess liquid immediately with a clean cloth or sponge; let the leather air dry. If further cleaning is necessary, sponge the entire surface with clean, lukewarm water. Let the leather air dry; never use a hair dryer or other heat source to dry leather. For stubborn spots and stains, apply a mild, nonabrasive soap solution with a clean, wet sponge. Rinse well and let air dry. For butter, oil, or grease, wipe the leather with a clean, dry cloth and let the remainder of the oil dissipate into the leather. Do not apply water or try to wash a grease spot. Do not use saddle soap, cleaning solvents, oils, furniture polishes, varnishes, abrasive cleaners, detergents, or ammonia on leather; they will ruin the finish, causing it to become sticky and cracked.

ENVIRONMENT

Parts can be separated and sorted for recycling.

INSTALLATION INSTRUCTIONS

56-15-300-02 Mounting instr. Adnet Circular Mirror.

DK **EN** **DE**

REINIGUNG **CLEANING** **REINIGUNG**

REINIGUNG **CLEANING** **REINIGUNG**

TECHNISCHE DATEN

56-15-300-02 Mounting instr. Adnet Circulaire Mirror

GUBI

Kubornweg 7-10 | 74634 Biss | T +49 3302 6300
2160 Nordhorn, Osterhagen | D 481 1702024 | WWW.GUBI.DE

GUBI **MONTAGEANLEITUNG** **ASSEMBLY INSTRUCTIONS** **MONTAGEANLEITUNG**

INHALTS/CONTENTS/INHALT **ADNET CIRCULAIRE**

1. DK: Montage der Halter.
EN: How to mount the bracket.
DE: Montage der Halterung.

2. DK: Montage der Metallspalte für den Magnet.
EN: How to mount the metal spacer for the magnet.
DE: Montage der Abstandshalter für den Magnet.

DK: Holzbohrung. **EN: Wooden wall.** **DE: Holzbohrung.**

DK: Betonbohrung. **EN: Concrete wall.** **DE: Betonbohrung.**

DK: Montieren den montierbare magnetische auf wæggen 25 mm fra bunden af spjeldet. Magnetens på baggrunden af spjeldet vil dermed sikre, at det altid hænger helt og til væggen.

EN: Mount the enclosed metal spacer on the wall 25 mm from the bottom of the mirror. The magnet on the back of the mirror will then ensure, that it always hangs close to the wall.

DE: Montieren Sie die beigefugte Metallspalte in der Höhe von 2,5 cm vom unteren Rahmen des Spiegels an der Wand. Der Magnet auf der Rückseite des Spiegels wird dadurch sichern, dass der Spiegel immer an der Wand hängt.

MINIMUM CEILING HEIGHT

