

# E-BIKE ASSEMBLY GUIDE

40 min



1 Cut the tape on top edges to lift the top sides to unbox your e-bike.

2 Additionally, carefully cut the box on the sides to use as a base for assembling

3 Find the tools and parts included. (may vary by model)

**1-2 WEEKS**  
It is recommended, whenever possible, to keep the box for 1-2 weeks in case of return.

**STEP 1** Carefully cut the tape from the box top edges, avoid cutting the bike inside. Then open the box from the top to see the contents. You may want to cut the box on the side to use it as a base to lay your e-bike for assembly.

↑ THIS SIDE UP  
DO NOT UNFASTEN  
Cyrusher.com

↑ THIS SIDE UP  
DO NOT UNFASTEN  
Cyrusher.com

**STEP 2** Unbox your brand new Cyrusher e-bike. We suggest you use one side of the box to protect the paint from scratches when assembling the bike.

Top bolt  
Side bolts

**STEP 3** Using the tools provided loose the top and side stem bolts.

180°  
(Lower part) Facing front

**STEP 4** Rotate the stem head 180°  
**NOTE:** The lower part should not rotate (make sure you loosen the top bolt before rotating the top part.)

**STEP 5** Release the 4 front bolts of the stem cover.

**STEP 6** Separate them.

**STEP 7** Place the handlebar inside the stem.  
Computer display facing inwards.  
Cabling facing outside.

**STEP 8** Screw bolts loosely into position to allow handlebar to be adjusted before fixing it firmly into place by tightly screwing the bolts into position.  
Fasten in an X order for a better tightening.

Insert the seat post into the frame.

Adjust to your height.  
Fasten the side nut.  
Push the handle lever to lock.

Both disc rotors to be on the same side.

**STEP 10** Turn the bike over so the front fork faces up and install the front wheel (make sure disc rotors from the front and rear wheels are on the same side).

The disc rotor must fit inside the disc brake perfectly.

head nut  
spring  
spring nut lever handle  
1 2 3 4 5

**STEP 11** Place bolts and springs in the order shown. (The lever handle can be on either side.) Twist on the head nut before firmly securing the lever handle.

Remove the headlight bolt.

Fasten clockwise.

**STEP 12** If included, attach headlight by removing front headlight bolts and positioning headlight before loosely screwing bolts back in place. Finally, adjust the headlight to the desired position then tighten.

**STEP 13** Choose the correct Left (L) and right (R) pedals (look for the marks), important to avoid damage the crank, then insert it into the crank aperture.

L (WL)  
R (WR)  
Choose the correct Left and Right pedal.

**STEP 14** Manually turn the pedal clockwise (some pressure may be needed to guide it in), then use the wrench to tighten the bolt.

Manually turn clockwise to guide the pedal in.  
Use the wrench to tighten the bolt and secure it.

Use provided air pump to inflate the tires.

See suggested pressure on the sidewall.  
INFLATE TO XX.X PSI

**STEP 15** Use the air pump provided to Inflate the tires to the suggested pressure indicated in the sidewall of the tire.  
**IMPORTANT:** Do not overinflate or underinflate the tires.

Congratulations! You've made it! Now enjoy your new Cyrusher E-Bike!

2021/7 V2-H for Cyrusher XF650/ XF800/XF900

Need more information? visit [www.cyrusher.com](http://www.cyrusher.com)